

Алматы (7273)495-231
Ангарск (3955)60-70-56
Архангельск (8182)63-90-72
Астрахань (8512)99-46-04
Барнаул (3852)73-04-60
Белгород (4722)40-23-64
Благовещенск (4162)22-76-07
Брянск (4832)59-03-52
Владивосток (423)249-28-31
Владикавказ (8672)28-90-48
Владимир (4922) 49-43-18
Волгоград (844)278-03-48
Вологда (8172)26-41-59
Воронеж (473)204-51-73
Екатеринбург (343)384-55-89

Ижевск (3412)26-03-58
Иваново (4932)77-34-06
Иркутск (395)279-98-46
Казань (843)206-01-48
Калининград (4012)72-03-81
Калуга (4842)92-23-67
Кемерово (3842)65-04-62
Киров (8332)68-02-04
Коломна (4966)23-41-49
Кострома (4942)77-07-48
Краснодар (861)203-40-90
Красноярск (391)204-63-61
Курск (4712)77-13-04
Курган (3522)50-90-47
Липецк (4742)52-20-81

Киргизия (996)312-96-26-47

Магнитогорск (3519)55-03-13
Москва (495)268-04-70
Мурманск (8152)59-64-93
Набережные Челны (8552)20-53-41
Нижний Новгород (831)429-08-12
Новокузнецк (3843)20-46-81
Ноябрьск (3496)41-32-12
Новосибирск (383)227-86-73
Ноябрьск (3496)41-32-12
Омск (3812)21-46-40
Орел (4862)44-53-42
Оренбург (3532)37-68-04
Пенза (8412)22-31-16
Петрозаводск (8142)55-98-37
Псков (8112)59-10-37

Россия (495)268-04-70

Пермь (342)205-81-47
Ростов-на-Дону (863)308-18-15
Рязань (4912)46-61-64
Самара (846)206-03-16
Саранск (8342)22-96-24
Санкт-Петербург (812)309-46-40
Саратов (845)249-38-78
Севастополь (8692)22-31-93
Симферополь (3652)67-13-56
Смоленск (4812)29-41-54
Сочи (862)225-72-31
Ставрополь (8652)20-65-13
Сыктывкар (8212)25-95-17
Сургут (3462)77-98-35
Тамбов (4752)50-40-97

Казахстан (772)734-952-31

Тверь (4822)63-31-35
Тольятти (8482)63-91-07
Томск (3822)98-41-53
Тула (4872)33-79-87
Тюмень (3452)66-21-18
Улан-Удэ (3012)59-97-51
Ульяновск (8422)24-23-59
Уфа (347)229-48-12
Хабаровск (4212)92-98-04
Чебоксары (8352)28-53-07
Челябинск (351)202-03-61
Череповец (8202)49-02-64
Чита (3022)38-34-83
Якутск (4112)23-90-97
Ярославль (4852)69-52-93

<https://astoria.nt-rt.ru> || aom@nt-rt.ru

Кофемашины Core600

Core⁶⁰⁰



Caratteristiche

Characteristics



1

- IT Display
 - Indicatore pressione e livello caldaia
 - Settaggio temperature/pressioni
 - Visualizzazione pressione rete/erogazione *
 - Settaggio ora e data
 - Settaggio lingua
 - Spia scaldatazze *
 - Tasto autosteamer *
 - Tempo di erogazione gruppi
 - Visualizzazione allarmi
 - Impostazione modalità Economy
 - Visualizzazione contatori parziale / globale (inclusi tè e lavaggi)
 - Settaggio data, ora, giorno settimana, On / Off macchina
 - Spegnimento macchina (stand-by)

- Visualizzazione release firmware
- Visualizzazione grafico erogazione bevande
- Visualizzazione grafico consumi energetici

* Funzionalità presente solo in alcune versioni della macchina.

EN Display

- Pressure indicator and boiler level
- Setting the temperature/pressure
- Mains/dispensing pressure display *
- Setting the time and date
- Setting the language
- Cup warmer indicator light *
- Auto-steamer key *
- Group dispensing time

- Alarm display
- Configuring Economy mode
- Partial / complete counter display (including tea and washes)
- Setting date, time, day of the week, machine On / Off
- Machine shutdown (stand-by)
- Firmware release display
- Drink dispensing graphic display
- Energy consumption graphic display

* Functionality available on certain versions only.

2

- IT Griglia a ribaltina in ogni gruppo
Permettono di utilizzare la macchina sia per tazze da espresso sia per i bicchieri delle bevande a

3





- base latte.
EN Flap rack in each group
Allows the machine to be used both for espresso cups and for glasses of milk-based beverages.
- IT Luce Led Piano Lavoro
Permette al barista di lavorare in condizioni ottimali anche con visibilità ridotta come pub, club, ecc..
EN Led Work Light
Allows the "barista" to work in optimal conditions even in reduced visibility environments such as pubs, clubs, etc.

4

- IT Sei dosi preimpostate nella versione SAE.
EN Six different pre-set doses in the SAE version.

Scheda tecnica

Technical product sheet



1GR

COMPACT

2GR

3GR

^{IT} Voltaggio ^{EN} Voltage	V	120 / 230-400 / 240	120 / 230-400 / 240	120 / 230-400 / 240	230-400 / 240
^{IT} Potenza ^{EN} Rated power	W	2300 / 3000 / 3300	2900 / 2900 / 3100	2900 / 3700 / 4000	5300 / 5700
^{IT} Caldaia ^{EN} Boiler	Lt <i>UK gal</i>	6 1,3	7 1,5	10,5 2,3	17 3,7
^{IT} Lance acqua-vapore ^{EN} Water-steam wands	N°	1/1	1/1	1/2	1/2
^{IT} Larghezza ^{EN} Width	mm <i>in</i>	580 22,8	580 22,8	788 31	1030 405
^{IT} Profondità ^{EN} Depth	mm <i>in</i>	580 22,8	580 22,8	580 22,8	580 22,8
^{IT} Altezza ^{EN} Height	mm <i>in</i>	557 21,9	557 21,9	557 21,9	557 21,9
^{IT} Peso netto ^{EN} Net weight	kg <i>lb</i>	62,5 138	65,5 144	74,5 164	89,5 187
^{IT} Peso lordo ^{EN} Gross weight	kg <i>lb</i>	71,5 158	74,5 164	84,5 186	101,5 224

Colori

Colours

^{IT} Acciaio
^{EN} Steel

^{IT} Bianco
^{EN} White

^{IT} Rosso
^{EN} Red

^{IT} Carrozzeria
^{EN} Body



Алматы (7273)495-231
Ангарск (3955)60-70-56
Архангельск (8182)63-90-72
Астрахань (8512)99-46-04
Барнаул (3852)73-04-60
Белгород (4722)40-23-64
Благовещенск (4162)22-76-07
Брянск (4832)59-03-52
Владивосток (423)249-28-31
Владикавказ (8672)28-90-48
Владимир (4922)49-43-18
Волгоград (844)278-03-48
Вологда (8172)26-41-59
Воронеж (473)204-51-73
Екатеринбург (343)384-55-89

Ижевск (3412)26-03-58
Иваново (4932)77-34-06
Иркутск (395)279-98-46
Казань (843)206-01-48
Калининград (4012)72-03-81
Калуга (4842)92-23-67
Кемерово (3842)65-04-62
Киров (8332)68-02-04
Коломна (4966)23-41-49
Кострома (4942)77-07-48
Краснодар (861)203-40-90
Красноярск (391)204-63-61
Курск (4712)77-13-04
Курган (3522)50-90-47
Липецк (4742)52-20-81

Киргизия (996)312-96-26-47

Магнитогорск (3519)55-03-13
Москва (495)268-04-70
Мурманск (8152)59-64-93
Набережные Челны (8552)20-53-41
Нижний Новгород (831)429-08-12
Новокузнецк (3843)20-46-81
Ноябрьск (3496)41-32-12
Новосибирск (383)227-86-73
Ноябрьск (3496)41-32-12
Омск (3812)21-46-40
Орел (4862)44-53-42
Оренбург (3532)37-68-04
Пенза (8412)22-31-16
Петрозаводск (8142)55-98-37
Псков (8112)59-10-37

Россия (495)268-04-70

Пермь (342)205-81-47
Ростов-на-Дону (863)308-18-15
Рязань (4912)46-61-64
Самара (846)206-03-16
Саранск (8342)22-96-24
Санкт-Петербург (812)309-46-40
Саратов (845)249-38-78
Севастополь (8692)22-31-93
Симферополь (3652)67-13-56
Смоленск (4812)29-41-54
Сочи (862)225-72-31
Ставрополь (8652)20-65-13
Сыктывкар (8212)25-95-17
Сургут (3462)77-98-35
Тамбов (4752)50-40-97

Казахстан (772)734-952-31

Тверь (4822)63-31-35
Тольятти (8482)63-91-07
Томск (3822)98-41-53
Тула (4872)33-79-87
Тюмень (3452)66-21-18
Улан-Удэ (3012)59-97-51
Ульяновск (8422)24-23-59
Уфа (347)229-48-12
Хабаровск (4212)92-98-04
Чебоксары (8352)28-53-07
Челябинск (351)202-03-61
Череповец (8202)49-02-64
Чита (3022)38-34-83
Якутск (4112)23-90-97
Ярославль (4852)69-52-93

<https://astoria.nt-rt.ru> || aom@nt-rt.ru